

FRENCHKNOT

A BEAUTIFUL HOME

CARE INSTRUCTIONS

WOODEN OUTDOOR FURNITURE

Your new Adirondack outdoor furniture is made from beautiful Acacia wood – a durable hardwood. Finished with white weather resistant paint, your new outdoor furniture will last for many years to come.

Like all painted timber items, they will need a little care and maintenance to stay looking their best.

1. If you keep your furniture set near a pool or hot tub, hose it down and towel dry once a week. The chlorine from the water can accumulate over time and cause the weather resistant finish to deteriorate.
2. Wipe the chairs, tables and footstools dry after rain and wipe up any liquid that is spilled onto the furniture. With special attention to screw holes where water can pool. When the furniture is moist, the wood cells expand and this can cause the furniture to buckle and swell.
3. Keep your furniture off the grass as much as possible. Contact with the soil will cause the legs to decay prematurely.
4. When not in use, place waterproof covers over your furniture to prevent it being exposed to too much moisture.
5. Clean your furniture twice a year to remove a build up of dirt and air pollution that if left will cause the weather resistant finish to deteriorate over time. Use a mild soap solution. Rinse thoroughly and towel dry.
6. During the winter months, store your furniture set indoors or under a waterproof cover to keep them protected until ready for use in the warmer months.